

Liquid Screed Aftercare

Immediately following installation:

- Keep the environment sealed for 2 days;
- Protect the screed from sunlight & frost but do not cover with polythene

After 48 hours:

- You can walk on the screed;
- Open up all windows and doors during the day to release moisture;
- Close up at night

After 7 days you can:

- Start 21 day UFH cycle;
- Install partition walls, kitchen units, stairs etc.

Between 10 to 14 days:

- Lightly abrade the surface to aid absorption of the primer and remove surface laitance

Before applying floor finishes:

- Carry out a moisture test;
- Prime surface using an acrylic or epoxy primer;
- Use a flexible adhesive

Please note: storage of materials on the screed surface, accidental exposure to water, humid or cold environments will delay drying.